

# BULLETIN N° 113

## Interchangeability list Suntec AT2, ATE2 / Suntec ATUV

AT2	ATUV	Remarks
AT2 45 A 9547 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 45 A 9574 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 45 AK 9507 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2V 45 A 9647 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 45 B 9506 xP 0500/0700	ATUV 45 R 9861 6P 0700	+ Flange adaptor $\varnothing 32\text{-}\varnothing 54$ (ref. 3719003)
AT2 45 BK 9601 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 45 BK 9601 xP 0600	ATUV 45 R 9861 6P 0700	+ Change the coils (ref. 3713824)
AT2V 45 B 9651 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 45 C 9541 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 45 C 9543 xP 0600	ATUV 45 L 9860 6P 0700	+ Change the coils (ref. 3713824)
AT2 45 C 9543 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 45 C 9563 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Nozzle fitting (ref. 3723838) + Inlet and return fittings G1/4-G1/8 (ref. 3729745)
AT2 45 C 9594 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 45 C 9602 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Nozzle fitting (ref. 3723838) + Inlet and return fittings G1/4-G1/8 (ref. 3729745)
AT2V 45 C 9604 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 45 C 9616 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 45 D 9513 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Inlet/return and nozzle fittings from the old pump
AT2 45 D 9538 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 45 D 9544 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 45 D 9555 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Inlet/return and nozzle fittings from the old pump
AT2 45 D 9584 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 45 D 9603 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 45 D 9615 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Nozzle fitting (ref. 3723838) + Inlet and return fittings G1/4-G1/8 (ref. 3729745)
AT2V 45 D 9633 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 45 D 9638 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 55 B 9406 xP 0500/0700	ATUV 45 R 9861 6P 0700	+ Flange adaptor $\varnothing 32\text{-}\varnothing 54$ (ref. 3719003)
AT2 55 B 9515 xP 0500/0700	ATUV 45 R 9861 6P 0700	
AT2 55 C 9504 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 55 C 9549 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2 55 C 9572 xP 0500	ATUV 45 L 9860 6P 0700	
AT2 55 CK 9571 xP 0500	ATUV 45 L 9860 6P 0700	+ Nozzle fitting (ref. 3753948)
AT2V 55 C 9672 xP 0500/0700	ATUV 45 L 9860 6P 0700	
AT2V 55 CK 9605 xP 0500/0700	ATUV 45 L 9860 6P 0700	+ Nozzle fitting (ref. 3753948)

1/2

ATE2	ATUV	Remarks
ATE2V 45 C 9305 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2V 45 C 9306 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2V 45 C 9315 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2V 45 C 9355 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2 55 D 9351 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2 55 D 9353 xP 0500/0700	ATUV 45 L 9860 6P 0700	
ATE2V 55 D 9354 xP 0500/0700	ATUV 45 L 9860 6P 0700	