

BULLETIN N° 48

Interchangeability list - Danfoss/Suntec

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 10 L6 071N0272	AE 57C 7373 4P		
BFP 10 L6 071N0276	AE 57C 7373 4P		DANFOSS: Pump in one-pipe configuration
BFP 10 L8 071N6111	AE 67C 7361 4P		
BFP 10 L11 071N6107	AE 77C 7380 2P		
BFP 10 L13 071N6103	AE 97C 7390 2P		+ Kit 991492
BFP 10 R3 071N0177	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 10 R3 071N0288	AN 47B 1395 6P	AN 47A 1326 6P	DANFOSS: Pump in one-pipe configuration
BFP 10 R5 071N0166	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 10 R6 071N0273		ANV 57A 7359 4P	SUNTEC pump has an hydraulic cut-off, 14 bars max.
BFP 10 R6 071N0277		ANV 57A 7359 4P	SUNTEC pump has an hydraulic cut-off, 14 bars max. DANFOSS pump in one-pipe configuration
BFP 10 R8 071N6112		AN 67A 7345 4P	SUNTEC pump has an hydraulic cut-off
BFP 10 R11 071N6108		AN 77A 7346 2P	SUNTEC pump has an hydraulic cut-off
BFP 10 R13 071N6104		AN 97A 7391 2P	SUNTEC pump has an hydraulic cut-off
BFP 11 L3 071N0101	AUV 47 L 9857 6P 0700		
BFP 11 L3 071N0114	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	SUNTEC: Shaft with one flat DANFOSS: Shaft with two flats
BFP 11 L3 071N0141	AUV 47 L 9857 6P 0700		DANFOSS: Pump in one-pipe configuration
BFP 11 L3 071N0142	AUV 47 L 9857 6P 0700		DANFOSS: Pump in one-pipe configuration
BFP 11 L3 071N0144	AUV 47 L 9857 6P 0700		
BFP 11 L3 071N0146	AUV 47 L 9857 6P 0700		
BFP 11 L3 071N0152	AUV 47 L 9857 6P 0700		
BFP 11 L3 071N0153	AUV 47 L 9857 6P 0700		Change Suntec pump coil (new 24V coil ref. 3713823)
BFP 11 L3 071N0184	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	

*seen from shaft end.

1/11

SB48-GB / Ed.7 - 11/01/2018



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 11 L3 071N0210	AUV 47 L 9857 6P 0700		
BFP 11 L3 071N0213	AUV 47 L 9857 6P 0700		
BFP 11 L5 071N0105	AUV 47 L 9857 6P 0700		
	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 11 L5 071N0178	AUV 47 L 9857 6P 0700		
	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 11 L6 071N1270	AS 57C 1583 6P 0700		SUNTEC: 14 bars max.
BFP 11 L6 071N1274	AS 57C 1583 6P 0700		SUNTEC: 14 bars max. DANFOSS: Pump in one-pipe configuration
BFP 11 L8 071N6109	AL 65C 9589 6P 0700		SUNTEC: 15 bars max.
BFP 11 R3 071N0143	AUV 47 R 9856 6P 0700		
BFP 11 R3 071N0145	AUV 47 R 9856 6P 0700		
BFP 11 R3 071N0155	AUV 47 R 9856 6P 0700		
BFP 11 R3 071N0181	AUV 47 R 9856 6P 0700		
BFP 11 R3 071N0183	AUV 47 R 9856 6P 0700		
BFP 11 R6 071N0271		AS 57A 7591 4P 0700	
BFP 11 R6 071N0275		AS 57A 7591 4P 0700	DANFOSS: Pump in one-pipe configuration
BFP 11 R6 071N1271		AS 57A 7591 4P 0700	SUNTEC: 14 bars max.
BFP 11 R6 071N1275		AS 57A 7591 4P 0700	SUNTEC: 14 bars max. DANFOSS: Pump in one-pipe configuration
BFP 11 R8 071N6110	AL 65B 9532 6P 0700		
BFP 11 R11 071N6106	AL 75B 9539 6P 0700		SUNTEC: 15 bars max. and left nozzle outlet DANFOSS: Right nozzle outlet
BFP 12 L6 071N6217	A2L 65 CK 9704 4P 0700		
BFP 12 L8 071N6210	A2L 65 CK 9704 4P 0700		
BFP 12 L11 071N6202	A2L 75 CK 9701 4P 0700		
BFP 12 L13 071N6203		A2L 95 D 9702 4P 0700	SUNTEC: Right nozzle outlet DANFOSS: Left nozzle outlet
BFP 12 R6 071N6218		A2L 65 A 9708 4P 0700	
BFP 12 R8 071N6219		A2L 65 A 9708 4P 0700	
BFP 12 R11 071N6214	A2L 95 B 9711 4P 0700		SUNTEC: Right nozzle outlet DANFOSS: Left nozzle outlet
BFP 12 R13 071N6220	A2L 95 B 9711 4P 0700		

*seen from shaft end.

2/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 20 L3 071N0108	AN 47 C 1342 6P	AN 47 D 1339 6P	
BFP 20 L3 071N0125	AN 47 C 1342 6P	AN 47 D 1339 6P	
BFP 20 L3 071N0127	AN 47C 1342 6P	AN 47D 1339 6P	
BFP 20 L3 071N0161	AN 47C 1342 6P	AN 47D 1339 6P	
BFP 20 L3 071N0168	AN 47C 1342 6P	AN 47D 1339 6P	
BFP 20 L3 071N0212	AN 47C 1342 6P	AN 47D 1339 6P	<i>SUNTEC: Shaft with one flat DANFOSS: Shaft with two flats</i>
BFP 20 L3 071N0267	AN 47C 1342 6P	AN 47D 1339 6P	
	AUV 47 L 9857 6P 0700		
BFP 20 L3 071N0295	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 20 L5 071N0126	AN 47C 1342 6P	AN 47D 1339 6P	
BFP 20 R3 071N0118	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R3 071N0128	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R3 071N0162	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R3 071N0169	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R3 071N0229	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R3 071N0298	AN 47B 1395 6P	AN 47A 1326 6P	<i>DANFOSS: Pump in one-pipe configuration</i>
BFP 20 R5 071N0129	AN 47B 1395 6P	AN 47A 1326 6P	
BFP 20 R5 071N0180	AN 47B 1395 6P	AN 47A 1326 6P	
	AUV 47 L 9857 6P 0700		
BFP 21 L2 071N2123	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
	AUV 47 L 9857 6P 0700		
BFP 21 L3 071N0102	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
	AUV 47 L 9857 6P 0700		
BFP 21 L3 071N0103	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
	AUV 47 L 9857 6P 0700		
BFP 21 L3 071N0104	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
	AUV 47 L 9857 6P 0700		
BFP 21 L3 071N0111	AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	

*seen from shaft end.

3/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 L3 071N0113	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0119	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0122	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0123	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	<i>Change Suntec pump coil (new 110V coil ref. 3713824)</i>
BFP 21 L3 071N0130	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0132	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0147	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0148	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0150	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0151	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0156	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	<i>DANFOSS: Pump in one-pipe configuration</i>
BFP 21 L3 071N0164	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	

*seen from shaft end.

4/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 L3 071N0170	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0175	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0176	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	<i>Change Suntec pump coil (new 110V coil ref. 3713824)</i>
BFP 21 L3 071N0179	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0182	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0185	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0189	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	<i>Change Suntec pump coil (new 24V coil ref. 3713823)</i>
BFP 21 L3 071N0193	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0197	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0204	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0209	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0217	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	

*seen from shaft end.

5/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 L3 071N0226	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N0228	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N1214	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	<i>DANFOSS: Pump in one-pipe configuration</i>
BFP 21 L3 071N1217	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 071N1219	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L3 L2 071N2130	AUV 47 L 9857 6P 0700		
BFP 21 L3 LE 071N2103	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2104	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2108	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2110		ALE V35D 9337 6P 0700	
BFP 21 L3 LE 071N2112	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2113	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2114	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N2118		ALE V35D 9337 6P 0700	
BFP 21 L3 LE 071N2119	ALE 35C 9324 6P 0700		
BFP 21 L3 LE 071N4105		ALE V35D 9337 6P 0700	
BFP 21 L3 LE-S 071N0233	ALE 35C 9324 6P 0700		<i>SUNTEC: Shaft with one flat DANFOSS: Shaft with two flats</i>
BFP 21 L3 LE-S 071N0264	ALE 35C 9324 6P 0700		
BFP 21 L3 LE-S 071N2116	ALE 35C 9324 6P 0700		
BFP 21 L3 LE-S 071N2125	ALE 35C 9324 6P 0700		
BFP 21 L3 LE-S 071N2128	ALE 35C 9339 6P 0700		
BFP 21 L3 LE-S 071N2225	ALE 35C 9324 6P 0700		
BFP 21 L3 LE-S 071N2303	ALE 35C 9324 6P 0700		<i>SUNTEC: Shaft with one flat DANFOSS: Shaft with two flats</i>
BFP 21 L5 071N0107	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	

*seen from shaft end.

6/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 L5 071N0116	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0158	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0172	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0194	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0202	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0227	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 071N0292	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 21 L5 LE-S 071N2131	ALE 35C 9339 6P 0700		
BFP 21 R3 071N0109	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0112	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0136	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0154	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0157	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	DANFOSS: Pump in one-pipe configuration

*seen from shaft end.

7/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 R3 071N0167	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0171	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0198	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0208	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0214	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0215	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R3 071N0231	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	<i>DANFOSS: Pump in one-pipe configuration</i>
BFP 21 R3 071N1215	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	<i>DANFOSS: Pump in one-pipe configuration</i>
BFP 21 R5 071N0120	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R5 071N0159	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R5 071N0163	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R5 071N0165	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	

*seen from shaft end.

8/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 21 R5 071N0173	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R5 071N0195	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 21 R5 071N0207	AUV 47 R 9856 6P 0700 AS 47B 1537 6P 0700	AS 47A 1536 6P 0700 AL 35A 9526 6P 0700	
BFP 31 L3 071N0115	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N0133	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	DANFOSS: Pump in one-pipe configuration
BFP 31 L3 071N0149	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N0190	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N0191	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N0192	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N1201	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 071N1203	AUV 47 L 9857 6P 0700 AS 47C 1538 6P 0700 AL 35C 9528 6P 0700	AS 47D 1539 6P 0700 AL 35D 9622 6P 0700	
BFP 31 L3 LE 071N2109	ALE 35C 9324 6P 0700		
BFP 41 L3 071N0135	AUV 47 L 9857 6P 0700		
BFP 41 L3 071N0160	AUV 47 L 9857 6P 0700		SUNTEC: Coil on the top DANFOSS: Coil at one side of the body

*seen from shaft end.

9/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 41 L3 071N0174	AUV 47 L 9857 6P 0700		
BFP 41 L3 071N0188	AUV 47 L 9857 6P 0700		
BFP 41 L3 071N0224	AUV 47 L 9857 6P 0700		
BFP 41 L3 071N0225	AUV 47 L 9857 6P 0700		
BFP 41 L3 071N1213	AUV 47 L 9857 6P 0700		
BFP 41 R3 071N0137/138	AUV 47 R 9856 6P 0700		<i>SUNTEC: Coil on the top DANFOSS: Coil at one side of the body</i>
BFP 41 R3 071N0196	AUV 47 R 9856 6P 0700		
BFP 41 R3 071N0235	AUV 47 R 9856 6P 0700		
BFP 51 L6 071N6204	AP2 65C 9511 4P 0700		
BFP 51 L8 071N6222	AP2 65C 9511 4P 0700		
BFP 51 L11 071N6205	AP2 95C 9590 4P 0700		
BFP 51 L13 071N6225	AP2 95C 9590 4P 0700		
BFP 51 R6 071N6221	AP2 65B 9523 4P 0700		
BFP 51 R8 071N6223	AP2 65B 9523 4P 0700		
BFP 52 L6 071N6206	ATUV 45 L 9860 6P 0700 AT2 55C 9549 4P 0700		
BFP 52 L8 071N6207	AT2 65C 9556 4P 0700		
BFP 52 L11 071N6209	AT2 75C 9583 4P 0700		
BFP 52 L13 071N6211	AT2 95C 9585 4P 0700		
BFP 52 R6 071N6227	ATUV 45 R 9861 6P 0700 AT2 55B 9515 4P 0700		
BFP 52 R8 071N6208	AT2 65B 9587 4P 0700		
BFP 52 R11 071N6210	AT2 75B 9591 4P 0700		
BFP 52 R13 071N6212	AT2 95B 9592 4P 0700		
BFP 52E L3 071N2201	ATUV 45 L 9860 6P 0700		
BFP 52E L3 071N2209	ATUV 45 L 9860 6P 0700		
BFP 52E L3 071N2211	ATUV 45 L 9860 6P 0700		<i>SUNTEC: Shaft with one flat DANFOSS: Shaft with two flats</i>
BFP 52E L3 071N2213	ATUV 45 L 9860 6P 0700		
BFP 52E L3 071N2264	ATUV 45 L 9860 6P 0700		
BFP 52E L3 LE-S 071N2222	ATUV 45 L 9860 6P 0700		
BFP 52E L3 LE-S 071N4222	ATUV 45 L 9860 6P 0700		
BFP 52E L5 071N2202	ATUV 45 L 9860 6P 0700		
BFP 52E L5 071N2205	ATUV 45 L 9860 6P 0700		

*seen from shaft end.

10/11



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC		Remarks
	Left-hand nozzle outlet*	Right-hand nozzle outlet*	
BFP 52E L5 071N2212	ATUV 45 L 9860 6P 0700		
BFP 52E L5 071N2217	ATUV 45 L 9860 6P 0700		
BFP 52E L5 071N2220	ATUV 45 L 9860 6P 0700		
BFP 52E L5 071N2265	ATUV 45 L 9860 6P 0700		
BFP 52E R3 071N2203	AT2 55B 9515 4P 0700	ATUV 45 R 9861 6P 0700	
BFP 52E R5 071N2204	AT2 55B 9515 4P 0700	ATUV 45 R 9861 6P 0700	
BFP 53 L6 071N6213	AT3 55C 9550 4P 0700		
BFP 53 L8 071N6229	AT3 65C 9561 4P 0700		

*seen from shaft end.