

BULLETIN Nr 48

Austauschliste - Danfoss/Suntec

DANFOSS	SUNTEC	Bemerkungen
BFP 10 L6 071N0272	AE 57 C 7373 4P	
BFP 10 L6 071N0276	AE 57 C 7373 4P	<i>Im Einstrangsystem zu konvertierende AE</i>
BFP 10 L8 071N6111	AE 67 C 7361 4P	
BFP 10 L11 071N6107	AE 77 C 7380 2P	
BFP 10 L13 071N6103	AE 97 C 7390 2P	<i>+ Kit 991492</i>
BFP 10 R3 071N0177	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 10 R3 071N0288	AUV 47 R 9876 6P 0700 + Kit 991401	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 10 R5 071N0166	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 10 R6 071N0273	AN V 57 A 7359 4P	<i>AN: Hydraulischer Abschnitt, 14 bar max.</i>
BFP 10 R6 071N0277	AN V 57 A 7359 4P	<i>AN: Hydraulischer Abschnitt, 14 bar max., im Einstrangsystem zu konvertierende</i>
BFP 10 R8 071N6112	AN 67 A 7345 4P	<i>AN: Hydraulischer Abschnitt</i>
BFP 10 R11 071N6108	AN 77 A 7346 2P	<i>AN: Hydraulischer Abschnitt</i>
BFP 10 R13 071N6104	AN 97 A 7391 2P	<i>AN: Hydraulischer Abschnitt</i>
BFP 11 L3 071N0101	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0114	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0141	AUV 47 L 9877 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 11 L3 071N0142	AUV 47 L 9877 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 11 L3 071N0144	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0146	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0152	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0153	AUV 47 L 9877 6P 0700	<i>AUV: die Spule auswechseln (24V ref. 3713823SAV)</i>
BFP 11 L3 071N0184	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0210	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N0213	AUV 47 L 9877 6P 0700	
BFP 11 L3 071N7141	AUV 47 L 9877 6P 0700	
BFP 11 L5 071N0105	AUV 47 L 9877 6P 0700	
BFP 11 L5 071N0178	AUV 47 L 9877 6P 0700	
BFP 11 L6 071N1270	AS 57 C 1583 6P 0700	<i>AS: 14 bar max.</i>
BFP 11 L6 071N1274	AS 57 C 1583 6P 0700	<i>AS: 14 bar max., im Einstrangsystem zu konvertierende</i>
BFP 11 L8 071N6109	AL 65 C 9589 6P 0700	<i>AL: 15 bar max.</i>
BFP 11 R3 071N0143	AUV 47 R 9876 6P 0700	
BFP 11 R3 071N0145	AUV 47 R 9876 6P 0700	
BFP 11 R3 071N0155	AUV 47 R 9876 6P 0700	
BFP 11 R3 071N0181	AUV 47 R 9876 6P 0700	

SB48-D / Ed.9 - 16/07/2019

1/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 11 R3 071N0183	AUV 47 R 9876 6P 0700	
BFP 11 R3 071N7155	AUV 47 R 9876 6P 0700	
BFP 11 R6 071N0271	AS 57 A 7591 4P 0700	
BFP 11 R6 071N0275	AS 57 A 7591 4P 0700	<i>Im Einstrangsystem zu konvertierende AS</i>
BFP 11 R6 071N1271	AS 57 A 7591 4P 0700	<i>AS: 14 bar max.</i>
BFP 11 R6 071N1275	AS 57 A 7591 4P 0700	<i>AS: 14 bar max., Im Einstrangsystem zu konvertierende</i>
BFP 11 R8 071N6110	AL 65 B 9532 6P 0700	
BFP 11 R11 071N6106	AL 75 B 9539 6P 0700	<i>AL: 15 bar max. und Düsenausgang links</i>
BFP 12 L6 071N6217	A2L 65 CK 9704 4P 0700	
BFP 12 L8 071N6210	A2L 65 CK 9704 4P 0700	
BFP 12 L11 071N6202	A2L 75 CK 9701 4P 0700	
BFP 12 L13 071N6203	A2L 95 D 9702 4P 0700	
BFP 12 R6 071N6218	A2L 65 A 9708 4P 0700	
BFP 12 R8 071N6219	A2L 65 A 9708 4P 0700	
BFP 12 R11 071N6214	A2L 95 B 9711 4P 0700	
BFP 12 R13 071N6220	A2L 95 B 9711 4P 0700	
BFP 20 L3 071N0108	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L3 071N0125	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L3 071N0127	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L3 071N0161	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L3 071N0212	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L3 071N0267	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 L5 071N0126	AUV 47 L 9877 6P 0700 + Kit 991401	
BFP 20 R3 071N0118	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R3 071N0128	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R3 071N0162	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R3 071N0169	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R3 071N0229	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R3 071N0298	AUV 47 R 9876 6P 0700 + Kit 991401	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 20 R5 071N0129	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 20 R5 071N0180	AUV 47 R 9876 6P 0700 + Kit 991401	
BFP 21 L2 071N2123	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0102	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0103	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0104	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0111	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0113	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0119	AUV 47 L 9877 6P 0700	

SB48-D / Ed.9 - 16/07/2019

2/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 21 L3 071N0122	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0123	AUV 47 L 9877 6P 0700	<i>AUV: die Spule auswechseln (110V ref. 3713824SAV)</i>
BFP 21 L3 071N0130	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0132	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0147	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0148	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0150	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0151	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0156	AUV 47 L 9877 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 21 L3 071N0164	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0170	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0175	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0176	AUV 47 L 9877 6P 0700	<i>AUV: die Spule auswechseln (110V ref. 3713824SAV)</i>
BFP 21 L3 071N0179	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0182	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0185	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0189	AUV 47 L 9877 6P 0700	<i>AUV: die Spule auswechseln (24V ref. 3713823SAV)</i>
BFP 21 L3 071N0193	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0197	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0204	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0209	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0217	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0226	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0228	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N0295	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N1214	AUV 47 L 9877 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 21 L3 071N1217	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N1219	AUV 47 L 9877 6P 0700	
BFP 21 L3 071N7170	AUV 47 L 9877 6P 0700	
BFP 21 L3 L2 071N2130	AUV 47 L 9877 6P 0700	
BFP 21 L3 LE 071N2103	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2104	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2108	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2110	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2112	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2113	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2114	AUV 47L 9877 6P 0700	

SB48-D / Ed.9 - 16/07/2019

3/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 21 L3 LE 071N2118	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N2119	AUV 47L 9877 6P 0700	
BFP 21 L3 LE 071N3118	AUV 47 L 9877 6P 0700	
BFP 21 L3 LE 071N3119	AUV 47 L 9877 6P 0700	
BFP 21 L3 LE 071N4105	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N0233	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N0264	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N2116	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N2125	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N2128	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N2225	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N2303	AUV 47L 9877 6P 0700	
BFP 21 L3 LE-S 071N3136	AUV 47 L 9877 6P 0700	
BFP 21 L3 LE-S 071N3225	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0107	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0116	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0158	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0172	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0194	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0202	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0227	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N0292	AUV 47 L 9877 6P 0700	
BFP 21 L5 071N7172	AUV 47 L 9877 6P 0700	
BFP 21 L5 LE-S 071N2131	AUV 47L 9877 6P 0700	
BFP 21 R3 071N0109	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0112	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0136	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0154	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0157	AUV 47 R 9876 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 21 R3 071N0167	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0171	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0198	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0208	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0214	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0215	AUV 47 R 9876 6P 0700	
BFP 21 R3 071N0231	AUV 47 R 9876 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 21 R3 071N1215	AUV 47 R 9876 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 21 R3 071N7171	AUV 47 R 9876 6P 0700	

SB48-D / Ed.9 - 16/07/2019

4/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 21 R5 071N0120	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0159	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0163	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0165	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0173	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0195	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N0207	AUV 47 R 9876 6P 0700	
BFP 21 R5 071N7173	AUV 47 R 9876 6P 0700	
BFP 31 L3 071N0115	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N0133	AUV 47 L 9877 6P 0700	<i>Im Einstrangsystem zu konvertierende AUV</i>
BFP 31 L3 071N0149	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N0190	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N0191	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N0192	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N1201	AUV 47 L 9877 6P 0700	
BFP 31 L3 071N1203	AUV 47 L 9877 6P 0700	
BFP 31 L3 LE 071N2109	AUV 47L 9877 6P 0700	
BFP 41 L3 071N0135	AUV 47 L 9877 6P 0700	
BFP 41 L3 071N0160	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N0174	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N0188	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N0224	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N0225	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N1213	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 071N7174	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 L3 LE-S 071N3137	AUV 47 L 9877 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 R3 071N0137/138	AUV 47 R 9876 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 R3 071N0196	AUV 47 R 9876 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 R3 071N0235	AUV 47 R 9876 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 41 R3 071N7137	AUV 47 R 9876 6P 0700	<i>AUV: Spule auf der Oberseite</i>
BFP 51 L6 071N6204	AP2 65C 9511 4P 0700	
BFP 51 L8 071N6222	AP2 65C 9511 4P 0700	
BFP 51 L11 071N6205	AP2 95C 9590 4P 0700	
BFP 51 L13 071N6225	AP2 95C 9590 4P 0700	
BFP 51 R6 071N6221	AP2 65B 9523 4P 0700	
BFP 51 R8 071N6223	AP2 65B 9523 4P 0700	
BFP 52 L6 071N6206	ATUV 45 L 9860 6P 0700	<i>ATUV: P1=2-12 bar BFP52: P1=7-15 bar</i>

SB48-D / Ed.9 - 16/07/2019

5/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 52 L8 071N6207	AT2 65C 9556 4P 0700	
BFP 52 L11 071N6209	AT2 75C 9583 4P 0700	
BFP 52 L13 071N6211	AT2 95C 9585 4P 0700	
BFP 52 R6 071N6227	ATUV 45 R 9861 6P 0700	ATUV: P1=2-12 bar, duse= bis 3 GPH @1,8 cSt & 5 GPH @5 cSt BFP52: P1=7-15 bar
BFP 52 R8 071N6208	AT2 65B 9587 4P 0700	
BFP 52 R11 071N6210	AT2 75B 9591 4P 0700	
BFP 52 R13 071N6212	AT2 95B 9592 4P 0700	
BFP 52E L3 071N2201	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 071N2209	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 071N2211	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 071N2213	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 071N2264	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 071N3201	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 LE-S 071N2222	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 LE-S 071N3213	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 LE-S 071N3214	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 LE-S 071N3215	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L3 LE-S 071N4222	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2202	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2205	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2212	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2217	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2220	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N2265	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E L5 071N3202	ATUV 45 L 9860 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E R3 071N2203	ATUV 45 R 9861 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar

SB48-D / Ed.9 - 16/07/2019

6/7



SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: information@suntec.fr - www.suntec.fr

DANFOSS	SUNTEC	Bemerkungen
BFP 52E R3 071N3203	ATUV 45 R 9861 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E R5 071N2204	ATUV 45 R 9861 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 52E R5 071N3204	ATUV 45 R 9861 6P 0700	ATUV: P1=2-12 bar BFP52E: P1=7-15 bar
BFP 53 L6 071N6213	AT3 55C 9550 4P 0700	
BFP 53 L8 071N6229	AT3 65C 9561 4P 0700	

SB48-D / Ed.9 - 16/07/2019



7/7