

# BULLETIN N° 51

## Interchangeability list Suntec AE, AS, AL, ALE / Suntec AUV

AE	AUV	Remarks
AE 35 C 9850 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 37 C 1376 xP	AUV 47 L 9877 6P 0700	+ Kit 991401 AE : pressure gauge port on the top of the body
AE 45 C 1301 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 45 C 1360 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 45 C 1370 xM	AUV 47 L 9877 6P 0700	+ Kit 991401 + G1/4 - G1/8 Adapters (ref. 3729745) + G1/8 - R1/8 connections (ref. 3723760)
AE 45 C 1392 xP	AUV 47 L 9877 6P 0700	+ Kit 991401 + G1/4-M14 connections (ref. 3759801)
AE 45 D 1307 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 45 D 1308 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 47 A 1384 xP	AUV 47 R 9876 6P 0700	+ Kit 991401
AE 47 B 1366 xP	AUV 47 R 9876 6P 0700	+ Kit 991401
AE 47 B 7267 xP	AUV 47 R 9876 6P 0700	AE : 2 pressure ports on the body + Kit 991401 + Hub adaptor Ø32-Ø54 (ref. 3759833)
AE 47 C 1386 xP	AUV 47 L 9877 6P 0700	+ Kit 991401 AE pressure range : 2-12 bars
AE 47 C 1387 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 47 C 1397 xP	AUV 47 L 9877 6P 0700	+ Kit 991401
AE 47 C 7274 xM	AUV 47 L 9877 6P 0700	AE : 2 pressure ports on the body AUV to convert in one-pipe configuration + Kit 991401 + Flange adaptor Ø32-Ø54 (ref. 3719003)
AE 47 C 7368 xP	AUV 47 L 9877 6P 0700	AE : 2 pressure ports on the body + Kit 991401
AE V 47 C 1394 xP	AUV 47 L 9877 6P 0700	+ Kit 991401 AE pressure range : 3-12 bars
AE V 47 C 1398 xM	AUV 47 L 9877 6P 0700	+ Kit 991401 AE pressure range : 2-12 bars
AE 47 D 1378 xM	AUV 47 L 9877 6P 0700	+ Kit 991401 AUV to convert in one-pipe configuration
AE 47 D 1385 xP	AUV 47 L 9877 6P 0700	+ Kit 991401

→ The data given in this table are valid for one-pipe installations (AUV pumps are convertible into a one-pipe configuration).

1/5

SB51-GB / Ed.9 - 25/06/2018

SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: [information@suntec.fr](mailto:information@suntec.fr) - [www.suntec.fr](http://www.suntec.fr)



AS	AUV	Remarks
AS 47 A 1536 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 A 1589 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 A 1619 xP 0200	AUV 47 R 9876 6P 0700	<i>Change the coil (24V AC ref. 3713823)</i>
AS 47 A 7432 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)</i>
AS 47 A 7436 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body + Hub adaptor Ø32-Ø54 (ref. 3759833)</i>
AS 47 A 7509 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body Keep the AS pump nozzle connections + G1/4 - G1/8 Adapters (ref. 3729745)</i>
AS 47 A 7536 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body</i>
AS 47 A 7592 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body</i>
AS 47 AK 1564 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 AK 1602 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 AK 1612 xM 0500/0700	AUV 47 R 9876 6P 0700	<i>AUV to convert in one-pipe configuration</i>
AS 47 AK 1613 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 AK 7469 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)</i>
AS 47 AK 7564 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body</i>
AS V 47 A 1636 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS V 47 A 7472 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)</i>
AS V 47 AK 7512 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body</i>
AS 47 B 1537 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 B 1616 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 B 7445 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)</i>
AS 47 B 7470 xP 0500/0700	AUV 47 R 9876 6P 0700	<i>AS : pressure port on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)</i>
AS 47 BK 1551 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS V 47 B 1618 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS V 47 B 1637 xP 0500/0700	AUV 47 R 9876 6P 0700	
AS 47 C 1538 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 1569 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 1578 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 1603 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 1604 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 1620 xP 0100/0600	AUV 47 L 9877 6P 0700	<i>Change the coil (110V AC ref. 3713824)</i>
AS 47 C 1621 xP 0200	AUV 47 L 9877 6P 0700	<i>Change the coil (24V AC ref. 3713823)</i>

→ The data given in this table are valid for one-pipe installations (AUV pumps are convertible into a one-pipe configuration).

AS	AUV	Remarks
AS 47 C 1625 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 C 7434 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)
AS 47 C 7438 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Hub adaptor Ø32-Ø54 (ref. 3759833)
AS 47 C 7444 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)
AS 47 C 7461 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)
AS 47 C 7538 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body
AS 47 C 7541 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body
AS 47 CK 1554 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 CK 1582 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : horizontal pressure port on the body
AS 47 CK 1623 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 CK 7451 xM 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003) AUV to convert in one-pipe configuration
AS V 47 C 1627 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS V 47 C 1638 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS V 47 CK 1624 xM 0500/0700	AUV 47 L 9877 6P 0700	AUV to convert in one-pipe configuration
AS 47 D 1539 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 D 1550 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 D 1557 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 D 1568 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/8 - M8 connections (ref. 3723838) + G1/4 - M14 connections (ref. 3759801)
AS 47 D 1596 xP0500/0700	AUV 47 L 9877 6P 0700	
AS 47 D 1615 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 D 7435 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Flange adaptor Ø32-Ø54 (ref. 3719003)
AS 47 D 7439 xP 0500/0700	AUV 47 L 9877 6P 0700	AS : 2 pressure ports on the body + Hub adaptor Ø32-Ø54 (ref. 3759833)
AS 47 DK 1562 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 DK 1573 xM 0500/0700	AUV 47 L 9877 6P 0700	AUV to convert in one-pipe configuration
AS 47 DK 1586 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS 47 DK 1597 xP 0500/0700	AUV 47 L 9877 6P 0700	
AS V 47 D 1640 xP 0200	AUV 47 L 9877 6P 0700	Change the coil (24V AC ref. 3713823)
AS V 47 D 1696 xP 0500/0700	AUV 47 L 9877 6P 0700	

→ The data given in this table are valid for one-pipe installations (AUV pumps are convertible into a one-pipe configuration).

AL	AUV	Remarks
AL 30 C 9518 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 inlet connections (ref. 3723850) + G1/4 - G1/8 return connection (ref. 3729745) + G1/8 - M8 nozzle connection (ref. 3723838)
AL 30 C 9535 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/8 - M8 connections (3723838)
AL 30 C 9537 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 connections (ref. 3723850) + G1/8 - M8 connections (ref. 3723838)
AL 30 CK 9516 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 connections (ref. 3723850) + G1/8 - M8 connections (ref. 3723838)
AL V 30 C 9608 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 connections (ref. 3723850) + G1/8 - M8 connections (ref. 3723838)
AL V 30 C 9611 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 connections (ref. 3723850) + G1/8 - M8 connections (ref. 3723838)
AL V 30 CK 9612 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4-M10 connections (ref. 3723850) + G1/8 - M8 connections (ref. 3723838)
AL 35 A 9501 xP 0100/0600	AUV 47 R 9876 6P 0700	Change the coil (110V AC ref. 3713824)
AL 35 A 9526 xP 0500/0700	AUV 47 R 9876 6P 0700	
AL 35 A 9570 xP 0500/0700	AUV 47 R 9876 6P 0700	AL : side pressure port on the body on the nozzle side
AL 35 A 9596 xP 0500/0700	AUV 47 R 9876 6P 0700	AL : pressure port on the body on the nozzle side
AL V 35 A 9626 xP 0500/0700	AUV 47 R 9876 6P 0700	
AL 35 B 9580 xP 0500/0700	AUV 47 R 9876 6P 0700	AL : 2 pressure ports on the body
AL 35 C 9503 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9514 xP 0100/0600	AUV 47 L 9877 6P 0700	Change the coil (110V AC ref. 3713824)
AL 35 C 9519 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9521 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9528 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9533 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9540 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4 - G1/8 Adapters (ref. 3729745)
AL 35 C 9542 2P 25	AUV 47 L 9877 6P 0700	
AL 35 C 9545 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/8 - M8 connections (ref. 3723838)
AL 35 C 9553 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 C 9578 xP 0500/0700	AUV 47 L 9877 6P 0700	AL : 2 pressure ports on the body
AL 35 CK 9536 xP 0500/0700	AUV 47 L 9877 6P 0700	AL : 2 pressure ports on the body
AL V 35 C 9573 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL V 35 C 9614 xP 0100/0600	AUV 47 L 9877 6P 0700	Change the coil (110V AC ref. 3713824)
AL V 35 C 9619 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL V 35 C 9625 xP 0500/0700	AUV 47 L 9877 6P 0700	Keep the AL pump nozzle connections
AL V 35 C 9628 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL 35 D 9529 xP 0500/0700	AUV 47 L 9877 6P 0700	
AL V 35 D 9622 xP 0500/0700	AUV 47 L 9877 6P 0700	

→ The data given in this table are valid for one-pipe installations (AUV pumps are convertible into a one-pipe configuration).

4/5

SB51-GB / Ecd.9 - 25/06/2018

SUNTEC INDUSTRIES FRANCE

1, rue Lavoisier - CS 60102 - F-21603 LONGVIC Cedex

Tel.: +33 (0)3 80 70 60 70 - Fax: +33 (0)3 80 70 61 11

e-mail: [information@suntec.fr](mailto:information@suntec.fr) - [www.suntec.fr](http://www.suntec.fr)



ALE	AUV	Remarks
ALE 30 C 9336 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4 - G1/8 Adapters (ref. 3729745) + G1/8 - M8 connections (ref. 3723838)
ALE V 30 C 9300 xP 0500/0700	AUV 47 L 9877 6P 0700	+ G1/4 - G1/8 Adapters (ref. 3729745) + G1/8 - M8 connections (ref. 3723838)
ALE 35 C 9319 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9321 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9324 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9327 xP 0500/0700	AUV 47 L 9877 6P 0700	ALE : 2 pressure ports on the body
ALE 35 C 9329 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9331 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9333 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE 35 C 9334 xP 0500/0700	AUV 47 L 9877 6P 0700	ALE : 2 pressure ports on the body
ALE 35 CK 9328 xP 0500/0700	AUV 47 L 9877 6P 0700	ALE : 2 pressure ports on the body
ALE V 35 C 9317 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE V 35 C 9339 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE V 35C 9356 xP 0500/0700	AUV 47 L 9877 6P 0700	
ALE V 35 D 9337 xP 0500/0700	AUV 47 L 9877 6P 0700	

→ The data given in this table are valid for one-pipe installations (AUV pumps are convertible into a one-pipe configuration).